

Ą.





300 302 Initiate link quality control module, link quality link proxy module, and link quality link modules for each transceiver 304 Transmit customer traffic via primary channel, analyze and integrate analog (optical) and digital (router) information **-306** Detect packet errors in excess of threshold value or APD count value below threshold value -308 Detect "down" file, disable port, and route customer traffic to backup channel **√310** Transmit test traffic via primary channel, detect packet errors below threshold value and APD count value above threshold value √3.12 Dectect "up" file, enable port, and route customer traffic to primary channel

FIG 3